

Manual, Assembly instruction: Brodit 605643

Right mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Press the thin end of the enclosed gap opener into the upper and lower dashboard section, to widen the gap. Press the angled edge on the lower part of the ProClip into the gap next to the gap opener.

2. Press the upper part of the ProClip upward so the angled lower edge hooks behind the lower dashboard section. Pull out the gap opener.

3. Press the gap opener into the gap between the dashboard and the frame surrounding the air vent. Hook the angled edge on the upper part of the ProClip into the gap next to the gap opener. Press down on top of the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.