

Manual, Assembly instruction: Brodit 605680

Right mount



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Hook the upper edge of the ProClip under the dashboard overhang.
2. Press the lower part of the ProClip upward/forward and hook it over the frame surrounding the air vent.
3. The ProClip mount is in place.
4. The ProClip mount is in place.