

## Manual, Assembly instruction: Brodit 605737

Right mount



**Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.**

**1.** Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Hook the grooved upper edge under the frame surrounding the air vent.

**2.** Press forward/upward on the lower part of the ProClip and hook the grooved edge over the frame surrounding the air vent.

**3.** The ProClip mount is in place.

**4.** The ProClip mount is in place.