

Manual, Assembly instruction: Brodit 605772

Right mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any holder & equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount is to be installed. Peel off the adhesive tape cover. Pull out the rubber sealant on the A-post. Hook the angled lower edge of the mount behind the A-post.

2. Press the mount forward/upward so the angled upper edge hooks around the A-post.

3. Press down on top of the mount so it hooks into place properly.

4. The ProClip is in place.