

Manual, Assembly instruction: Brodit 605976

Right mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip mount first: any device holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Place the lower edge of the mount into the bottom of the air vent housing and hook it over + behind the bottom frame.
2. Press forward on top of the mount so the upper edge hooks + clips under + behind the frame surrounding the air vent housing.
3. Press forward on the mount so it is properly in place.
4. The ProClip mount is in place.