

Manual, Assembly instruction: Brodit 606029

Right mount NOT for models with A-post handle.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip mount first: any holder & equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Pull out the rubber sealant on the A-post slightly. Press the right part of the mount into the gap and hook it behind the A-post.
2. Press the mount upward/forward and hook the left angled edge over the A-post.
3. Press the left edge toward the A-post so the angled edge hooks into place properly.
4. The ProClip is in place.