

Manual, Assembly instruction: Brodit 606032

Right mount



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder & equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Place the lower edge of the mount onto the frame surrounding the air vent housing.
2. Press the upper part of the mount downward and forward.
3. Hook the upper edge of the mount under the frame surrounding the air vent housing.
4. The ProClip mount is in place.