

Manual, Assembly instruction: Brodit 606038

Right mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder & equipment is to be attached after the mount is in place.

1. Press the lower edge of the mount into the gap between the trim and the padded dashboard.
2. Press the mount upward and forward.
3. Lift the upper edge of the mount upwards so it does not touch the padded dashboard. Hook the angled edge of the mount into the gap between the padded dashboard and the panel. Press downward on top of the mount so the angled edge goes all the way into the gap.
4. The ProClip mount is in place.