


Manual, Assembly instruction: Brodit 606039

Right mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder & equipment is to be attached after the mount is in place.

1. Pull out the rubber sealant on the A-post slightly. Press the lower part of the mount into the gap and hook it behind the A-post.
2. Press the mount upward/forward and hook the upper angled edge over the A-post.
3. Press on top of the mount so it hooks into place properly.
4. The ProClip mount is in place.