

Manual, Assembly instruction: Brodit 606240

Right mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Press the lower edge of the mount into the gap between the air vent housing and the surrounding frame.
2. Press the upper part of the mount downward and forward so the upper edge starts to go into the gap between the air vent housing and the surrounding frame.
3. Press forward on top of the mount so the upper edge goes all the way into the gap between the air vent housing and the surrounding frame.
4. The ProClip mount is in place.