


Manual, Assembly instruction: Brodit 634484

Console mount, Low



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the seam/gap between the center console panel and the padded console edge, to widen the gap. Peel off the cover of adhesive tape on the ProClip.
2. Press the angled edge on the right side of the ProClip into the gap in front of the gap opener.
3. Place your thumbs on the top of the ProClip and your index fingers on the inside of the ProClip to make sure the angled edge clears off the console sidewall. Press down on top of the ProClip with your thumbs so the ProClip flexes downwards, and then hook the angled edge around the console edge by the carpet. Pull out the gap opener.
4. The ProClip is in place.