

Manual, Assembly instruction: Brodit 635013

Console mount, Left

1.)



2.)



3.)



4.)



Please read the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel of the adhesive tape cover on the ProClip. Press the thin end of the enclosed gap opener into the gap between the console edge and the center console panel. Then press the angled edge on the right side of the ProClip into the gap in front of the gap opener. Remove the gap opener.

2. Using your fingers, pull out the rubber edge next to the left part of the ProClip slightly, to widen the gap. At the same time, press down on top of the ProClip with your other so the ProClip flexes downward and the angled edge hooks into the gap.

3. The ProClip is in place.

4. The ProClip is in place.