

Manual, Assembly instruction: Brodit 635644

Console mount



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the center console top and frame, to widen the gap. Peel off the adhesive tape cover on the ProClip. Press the angled edge on the upper part of the ProClip into the gap next to the gap opener. Pull out the gap opener.

2. Press the gap opener into the gap in the center console side wall. Press downward on the left part of the ProClip and hook the J-shaped lower edge into the gap next to the gap opener.

3. Press on the mount so it is properly in place. Pull out the gap opener.

4. The ProClip is in place.