

Manual, Assembly instruction: Brodit 635780

Console mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any holder & equipment is to be attached after the mount is in place.

1. Press the thin end of the enclosed gap openers into the gap underneath the center console frame, to widen the gap. Use the enclosed alcohol pad to clean the area where the mount is to be installed. Peel off the adhesive tape cover.

2. Hook the right part of the mount over the center console frame.

3. Press down on the left side of the mount so the angled lower edge hooks into the gap between the gap opener. Press the left side of the mount upward toward the center console frame, so the angled edge goes all the way into the gap. Pull out the gap openers.

4. The ProClip is in place.