

Manual, Assembly instruction: Brodit 635790

Console mount



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any holder & equipment is to be attached after the mount is in place.

1. Hook the upper edge of the mount over the center console frame.
2. Press down on the left side of the mount and hook the lower edge under the center console frame.
3. Press the mount toward the center console frame so the angled edge goes all the way into the gap.
4. The ProClip is in place.