

Manual, Assembly instruction: Brodit 652428

Angled mount

1.)



2.)



3.)



4.)



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip. Important: The images shows an example ProClip, the actual ProClip comes with a tilt swivel as shown on image 4.

1. Clean the surface at Pos. 1 with the enclosed alcohol pad. Peel off the cover of adhesive tape on the ProClip. Place the angled edge on the right side of the ProClip into the gap between the center console panels and the console edge.
2. Press firmly forward on the left side of the ProClip so the curved edge on the left side of the ProClip hooks behind the console edge by the carpet.
3. Make sure the curved edge on the ProClip has hooked properly behind the console edge by pressing it towards the console wall + edge.
4. The ProClip is in place.