

Manual, Assembly instruction: Brodit 653199

Angled mount



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of the adhesive tape on the ProClip. Place the ProClip to the right of the right air vent, on the left side of the steering wheel. Hold the ProClip so the upper part is pointing towards you. Press the curved edge on the upper part of the ProClip upwards/towards you into the gap in the dashboard, under the dashboard ledge. Pull the lower part of the ProClip towards you, away from the dashboard, so the curved upper edge hooks into the gap.

2. Slide the ProClip leftwards, away from the steering wheel, until it is placed over the right air vent.

3. Press the lower part of the ProClip, with adhesive tape, into the gap between the dashboard and the air vent frame.

4. The ProClip is in place.