

Manual, Assembly instruction: Brodit 653209

Center mount



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the center control panel frame and the padded part of the dashboard, to widen the gap. Peel off the cover of the adhesive tape on the ProClip.
2. Press the grooved edge on the lower part of the ProClip into the gap next to the gap opener. Press until you see or hear/feel it snaps into place. Pull out the gap opener.
3. Press the thin end of the enclosed gap opener into the gap between the air vent frame and the dashboard, to widen the gap. Press forward on the upper part of the ProClip so the angled edge snaps into the gap next to the gap opener.
4. The ProClip is in place.