

Manual, Assembly instruction: Brodit 653365

Center mount, Low



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the dashboard and the center panel to widen the gap. Peel off the adhesive tape covers on the ProClip. Place the ProClip as shown in the picture.

2. Press the upper part of the ProClip into the gap next to the gap opener. Pull out the gap opener.

3. Press the gap opener into the gap between the panel and the frame surrounding the stereo. Press forwards on the lower part of the ProClip so it goes all the way into the gap next to the gap opener. Pull out the gap opener.

4. The ProClip is in place.