

Manual, Assembly instruction: Brodit 653481

Angled mount, Low


1.)




2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of the adhesive tape on the ProClip. Hook the right part of the ProClip over the edge of the console.
2. Press downwards on the left side of the ProClip so the long left part hooks under the edge of the console.
3. The ProClip is in place.
4. The ProClip is in place.