

Manual, Assembly instruction: Brodit 653574

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap openers into the gap in the control panel, above the stereo, to widen the gap. Peel off the adhesive tape covers on the ProClip.

2. Hook the angled edge on the upper part of the ProClip into the lower edge of the air vent housing.

3. Press forwards on the center and lower part of the ProClip, so the lower edge of the ProClip goes into the gap next to the gap opener. Pull put the gap opener.

4. The ProClip is in place.