

Manual, Assembly instruction: Brodit 653598

Center mount NOT for models with factory navigation system. NOT for wood grain panel.



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the frame surrounding the control panel, to widen the gap. Peel off the cover of the adhesive tape on the ProClip.

3. Press the grooved edge on the lower part of the ProClip into the gap next to the gap opener. Press until you hear/feel it snaps into place. Pull out the gap opener.

3. Press the gap opener into the gap between the frame surrounding the air vent and the dashboard. Press forwards on the ProClip so the angled upper edge hooks into the gap next to the gap opener. Pull out the gap opener.

4. The ProClip is in place.