

Manual, Assembly instruction: Brodit 653622

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin ends of the enclosed gap openers into the gap between the center console panel frame and the padded part of the dashboard as shown in the picture, to widen the gap.

2. Press the horizontal grooved edge on the ProClip into the gap next to the gap opener. Press until you see or hear/feel it snaps into place.

3. Press the vertical grooved edge on the ProClip into the gap above the gap opener. Press until you see or hear/feel it snaps into place. Pull out the gap openers.

4. The ProClip is in place.