

Manual, Assembly instruction: Brodit 653623

Angled mount NOT for wood grain panel.



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip is divided into two parts. Part 1: The attaching part (the smallest part) Part 2: The ProClip faceplate

1. Press the thin end of the enclosed gap opener into the gap between the center console panel frame and the console edge, to widen the gap. Peel off the cover of the adhesive tape on Part 1. Place Part 1 in the same position as in the picture, in the same height.

2. Press the angled edge firmly into the gap above the gap opener and at the same time: bend Part 1 to the left until you hear/feel it snaps into place and the adhesive tape attaches to the console edge.

3. Press a screwdriver (Philips) firmly through the predrilled holes in Part 2 to open them up. Peel off the cover of the adhesive tape on Part 2. Place Part 2 onto Part 1 so the holes match and the adhesive tape on Part 2 is on the right side attaching to the center console panel frame. Screw Part 2 onto Part 1 using the enclosed screws. When screwing in the lower screw press Part 2 to the left with your thumb for best possible alignment.

4. The ProClip is in place.