

Manual, Assembly instruction: **Brodit 653739**

Center mount NOT for models with factory navigation. ONLY for wood grain panel.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed Gap Opener (Spaltöffner)s upwards into the gap between the wood grain trim and the climate control panel frame, to widen the gap. Peel off the cover of adhesive tape on the ProClip.
2. Place + hook the grooved edge on the lower part of the ProClip into the gap between the Gap Opener (Spaltöffner)s.
3. Press forward on the upper part of the ProClip so the angled edge snaps over the wood grain trim and into the gap between the trim and the padded part of the dashboard. Press until you see or hear + feel it snaps into place. Pull out the Gap Opener (Spaltöffner)s.
4. The ProClip is in place.