

Manual, Assembly instruction: Brodit 653865

Center mount For models both with and without upper storage compartment.



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the trim and the dashboard, to widen the gap. Peel off the adhesive tape covers on the ProClip.
2. Press the curved edge on the upper part of the ProClip into the gap between the frame surrounding the coin compartment and the dashboard. Flip the ProClip downwards so the curved upper edge hooks under the frame surrounding the coin compartment.
3. Press the lower part of the ProClip into the gap between the gap openers. Pull out the gap openers.
4. The ProClip is in place.