

Manual, Assembly instruction: Brodit 653873

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the control panel and the dashboard and prize the frame surrounding the control panel loose slightly. Peel off the adhesive tape covers on the ProClip. Place the curved edge on the left part of the ProClip into the gap between the frame surrounding the control panel and the frame surrounding the air vent.

2. Pull out the gap opener. Press forward on the frame surrounding the control panel so it snaps back into place and the curved left edge of the ProClip is locked into place.

3. Press the gap opener into the gap between the frame surrounding the air vent and the dashboard and press forward on the gap opener so the gap is widened. In the same time press forward on the right side of the ProClip so the angled edge hooks into the gap above the gap opener. Pull out the gap opener. Press the right part of the ProClip toward the gap so the angled edge goes all the way into the gap.

4. The ProClip is in place.