

Manual, Assembly instruction: Brodit 653948

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the dashboard, to widen the gap. Peel off the adhesive tape covers on the ProClip.

2. Press the curved edge on the lower part of the ProClip into the gap between the climate control panel and the surrounding frame. Flip the ProClip upwards/forwards so the curved lower edge hooks behind the climate control panel.

3. Press forward on the upper part of the ProClip so the angled edge hooks into the gap next to the gap opener. Press downward on top of the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.