

Manual, Assembly instruction: Brodit 653980

Angled mount, High

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the dashboard and the control panel. Peel off both adhesive tape covers on the ProClip. Place the upper part of the ProClip, with angle, into the lower part of the air vent.

2. Hook the upper part of the ProClip onto the air vent by pulling it downwards and forward at the same time as you press the lower part downwards. Press the lower part of the ProClip into the gap next to the gap opener.

3. Press on the ProClip so it is properly in place and the adhesive tapes attach. Pull out the gap opener.

4. ProClip in place