

Manual, Assembly instruction: Brodit 653994

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Hook the angled edge on the right part of the ProClip into the gap between the panel by the gear shift and the floor console edge.
2. Press downward on the left side of the ProClip and hook the angled edge on the left part under the edge of the console.
3. Press the left edge of the ProClip toward the console side wall so the angled edge hooks under the console edge properly.
4. The ProClip is in place.