

Manual, Assembly instruction: Brodit 654135

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip consists of two parts. Part 1. Attaching part (the smallest part) Part 2. ProClip face plate

1. Press the thin end of the enclosed gap openers into the gap between the control panel and the dashboard, to widen the gap. Peel off the cover of the adhesive tape on Part 1. Press the angled edge of Part 1 into the gap between the gap openers.

2. Press Part 1 upward and forward so the angled edge hooks behind the control panel and the adhesive tape attaches to the dashboard. Pull out the gap openers.

3. Open up the predrilled holes in Part 2 with a screwdriver (Philips). Peel off the cover of the adhesive tape on Part 2. Place Part 2 onto Part 1 so the holes match. Screw Part 2 onto Part 1 with the enclosed screws.

4. The ProClip is in place.