

Manual, Assembly instruction: Brodit 654263

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip can be placed anywhere within the width of the air vents.

1. Clean the area where the ProClip is to be installed with the enclosed alcohol pad. Press the thin end of the enclosed gap openers into the gap between the frame surrounding the air vent and the control panel, to widen the gap. Peel off the adhesive tape covers on the ProClip.

2. Press the angled edge on the upper part of the ProClip into the gap between the frame surrounding the air vent and the panel surrounding the display, press it upward under the panel surrounding the display.

3. Squeeze the ProClip together and press the lower edge into the gap between the gap openers. Press forward on the lower part of the ProClip so the thin edge goes all the way into the gap. Pull out the gap openers.

4. The ProClip is in place.