

Manual, Assembly instruction: Brodit 654335

Center mount, will block heated seat switch Will block heated seat switch.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the control panel and the panel surrounding the display, to widen the gap. Peel off the adhesive tape cover on the ProClip. Press the left corner of the upper part of the ProClip into the gap next to the gap opener.

2. Press down on the right part of the ProClip so all of the angled edge goes into the gap. Slide the ProClip leftward in the gap, as far as possible. Pull out the gap opener.

3. Press the gap opener into the gap between the control panel and the surrounding frame. Press the lower part of the ProClip forward so the thin lower edge goes into the gap next to the gap opener. Press forward on the lower part of the ProClip so the edge goes all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.