

Manual, Assembly instruction: Brodit 654601

Center mount ONLY for models with VW multi use mounting points fitted. NOT for GPS devices.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip consists of two parts: Part 1: Attaching piece (the round part) Part 2: Mounting plate

1. Remove the round cover below the air vent. Place Part 1 in the hole (Part 1 only fits one way into the hole, if it does not fit turn Part 1 slightly to get it into the correct position in order to fit)

2. Turn Part 1 clockwise so you feel it is firmly in place. Tighten the screw in Part 1 slightly (not too hard) with the enclosed tool.

3. Place Part 2 onto Part 1 so the holes match. Screw part 2 onto Part 1 using the enclosed screws.

4. The ProClip is in place.