

Manual, Assembly instruction: Brodit 654617

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the curved edge on the right part of the ProClip into the gap between the control panel and the surrounding frame.
2. Flip the ProClip forward/leftward so the curved right edge hooks behind the control panel.
3. Press forward on the left side of the ProClip, in the same time press the left part toward the center console. Hook the angled edge on the left part of the ProClip into the gap between the frame surrounding the control panel and the center console sidewall.
4. The ProClip is in place.