

Manual, Assembly instruction: Brodit 654632

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the lower part of the ProClip into the gap between the panel surrounding the air vent and the center console.
2. Pull the upper part of the ProClip upward, then press it forward. Hook the angled upper edge into the gap between the panel surrounding the air vent and the frame surrounding the display.
3. Press downward on top of the ProClip so the angled edge goes all the way into the gap and the adhesive tape attaches.
4. The ProClip is in place.