

Manual, Assembly instruction: Brodit 654709

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip consists of two parts: Part 1: Attaching part (the smallest part) Part 2: ProClip face plate.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the control panel and the dashboard, to widen the gap. Peel off the adhesive tape cover on Part 1. Press Part 1 into the gap below the gap opener.

2. Press Part 1 forward and leftward so the angled edge hooks behind the control panel and the adhesive tape attaches. Pull out the gap opener.

3. Open up the predrilled holes in Part 2 with a screwdriver (Philips). Peel off the adhesive tape cover on Part 2. Place Part 2 onto Part 1 so the adhesive tape is placed on the right side and the holes match. Screw part 2 onto part 1 by using the enclosed screws.

4. The ProClip is in place.