

Manual, Assembly instruction: Brodit 654749

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the lower part of the ProClip into the gap between the panel surrounding the air vents and the dashboard.
2. Hook the angled edge on the upper part of the ProClip into the gap between the frame surrounding the air vent and the surrounding panel.
3. Press down on top of the ProClip so the angled edge goes all the way into the gap.
4. The ProClip is in place.