

Manual, Assembly instruction: Brodit 654825

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the center console panel and the panel surrounding the air vents, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the angled edge on the lower part of the ProClip into the gap next to the gap opener. Pull out the gap opener.

2. Press the gap opener into the gap between the upper dashboard ledge and the panel surrounding the air vents. Pull the upper part of the ProClip so it flexes upward and hook the angled edge into the gap next to the gap opener.

3. Press down on the top part of the ProClip to make sure the angled edge is all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.