

Manual, Assembly instruction: Brodit 654840

Center mount NOT for models with column gear shifter.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Hook/press the angled edge on the upper part of the ProClip into the air vent behind the frame surrounding the air vent.

2. Press the bottom part of the ProClip upward and into the the air vent. Push forward until you hear it click into place.

3. The ProClip is in place.

4. The ProClip is in place.