

Manual, Assembly instruction: Brodit 654857

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the lower part of the ProClip into the gap between the compartment and the surrounding frame.
2. Pull the lower part of the ProClip toward you so the angled edge hooks properly around the frame surrounding the compartment.
3. Press downward on top of the ProClip so the angled upper edge hooks under the frame surrounding the compartment.
4. The ProClip is in place.