

Manual, Assembly instruction: Brodit 654889

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important this ProClip is placed exactly as shown in the pictures.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed Gap Opener (Spaltöffner) into the gap surrounding the air vents and the dashboard, to widen the gap (see picture 2). Remove the adhesive tape cover on the ProClip. Angle the air vent so it points straight outward, to ensure most possible visibility into the air vent. Insert the angled bottom part of the ProClip into the lower edge of the air vent. Feel it snaps into the gap inside the air vent properly. Make sure you do not push it too far into the air vent.

2. Press the upper part of the ProClip into the gap next to the Gap Opener (Spaltöffner). Remove the Gap Opener (Spaltöffner).

3. Press onto the ProClip to make sure it is properly in place and the adhesive tape fastens.

4. The ProClip is in place.