

Manual, Assembly instruction: Brodit 654896

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip consists of two parts. Part 1. Attaching part Part 2. ProClip face plate.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the enclosed gap opener into the gap between the frame surrounding the display and the dashboard, to widen the gap.

2. Peel off the adhesive tape cover on Part 1. Press the grooved edge on Part 1 into the gap next to the gap opener, but do not allow the adhesive tape to attach yet. Press Part 1 into the gap until you hear/feel it snaps into place. Press down on Part 1 so the adhesive tape attaches.

3. Open up the predrilled holes in Part 2 with a screwdriver. Peel off the adhesive tape cover on Part 2. Place Part 2 onto Part 1 so the holes match. Attach Part 2 onto Part 1 with the enclosed screws.

4. The ProClip is in place.