

Manual, Assembly instruction: Brodit 654974

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip consists of two parts.
Part 1. Attaching part Part 2. Mounting plate

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on Part 1. Place Part 1 so the adhesive tape is pointing downward, and press the grooved edge into the gap between the frame surrounding the display and the panel in front of the display. Press until you hear + feel it snaps into place.

2. Open the predrilled holes in Part 2 with a screwdriver (Philips). Place Part 2 so the notch hooks into the upper part of the air vent and the holes match the holes in Part 1.

3. Attach Part 2 onto Part 1 by using the enclosed screws.

4. The ProClip is in place.