

Manual, Assembly instruction: Brodit 655007

Center mount

1.)



2.)



3.)



4.)



Please read the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel of the adhesive tape cover on the ProClip. Press the curved edge on the lower part of the ProClip into the gap in the panel underneath the dashboard overhang.
2. Push the front part of the ProClip upward.
3. Place your index fingers behind each side of the ProClip. Pull the ProClip towards you and then hook the angled edge over the air vent edge.
4. The ProClip is in place.