

Manual, Assembly instruction: Brodit 655044

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. NOTE: This ProClip can be placed anywhere along the width of the air vents.

1. Press the angled edge on the lower part of the ProClip into the gap between the frame surrounding the air vent and the control panel.
2. Press the ProClip upward and the upper part forward.
3. Press downward on top of the ProClip so the curved edge hooks under the frame surrounding the air vent.
4. The ProClip is in place.