

Manual, Assembly instruction: Brodit 655047

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape covers on the ProClip. Hook the angled lower edge of the ProClip around the upper edge of the air vent. **2** Press the angled upper part of the ProClip into the gap between the padded top of the dash board and the instrument panel.

3. Press the top part of the ProClip downward so the angled edge goes all the way into the gap and the tape adheres properly.

4. The ProClip is in place.