

Manual, Assembly instruction: Brodit 655063

Angled mount NOT for models with cup holder.



Please read the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Insert the thin end of the enclosed gap opener into the gap between the center console and the dash board, to widen the gap. Remove the adhesive tape covers on the ProClip.

2. Hold the ProClip at an angle above the gap next to the gap opener and press the curved edge of the upper part of the ProClip into the gap. Move the lower edge of the ProClip downward so the upper edge hooks behind the dash properly. Remove the gap opener.

3. Hook the angled lower edge of the ProClip around the bottom side of the center console. Press the angled lower edge upward so the adhesive tape fastens properly.

4. The ProClip is in place.