

Manual, Assembly instruction: Brodit 655069

Angled mount

1.)



2.)



3.)



4.)



Please read the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape covers on the ProClip. Press the upper corner of the ProClip into the gap on the center console side wall.
2. Press the remaining of the ProClip all the way into the gap.
3. The ProClip is in place.
4. The ProClip is in place.