

Manual, Assembly instruction: Brodit 655075

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed Gap Opener (Spaltöffner) into the gap under the stereo over hang, to widen the gap. Remove the adhesive tape cover on the ProClip. Press the angled top part of the ProClip upward and into the gap, next to the Gap Opener (Spaltöffner). Push the bottom part of the ProClip downward so the angled upper edge hooks behind the stereo. Remove the Gap Opener (Spaltöffner).

2. Press the thin end of the Gap Opener (Spaltöffner) into the gap between the climate control panel and the surrounding frame, to widen the gap. Push the bottom part of the ProClip forward + downward.

3. Press the right edge of the ProClip into the gap next to the Gap Opener (Spaltöffner). Remove the Gap Opener (Spaltöffner) and insert it again into the same gap on the other side of the ProClip. Press the angled left edge of the ProClip into the gap next to the Gap Opener (Spaltöffner). Remove the Gap Opener (Spaltöffner).

4. The ProClip is in place.